UNIVAC OPERATOR & PARTS MANUAL

P/N: MANUALXCU

Systems

REVISION SHEET FOR MANUALXCU

Release No.	Date	Revision Description	
1	03/11/20	Initial design/release of MANUALXCU	
2	06/18/20	Edit to 4.1, 4.2 and 4.3	

NOTE: Specifications and parts are subject to change without notice


Kaivac, Inc. 2680 Van Hook Ave. Hamilton, OH 45015


.

OPERATOR & PARTS MANUAL - TABLE OF CONTENTS

1.0 G	Getting Started	
	1.1 Product Identification	5
	1.2 Warranty Registration	5
	1.3 LIMITED WARRANTY PROTECTION PLAN	6
	1.4 Safety Precautions: Corded Units Only	7
	1.4 Safety Precautions: Corded (Continued)	8
	1.5 SAFETY PRECAUTIONS: BATTERY OPERATED UNITS ONLY	9
	1.5 Safety Precautions: Battery Operated (Continued)	10
	1.6 Battery Information	
2.0 O	Operation	
	2.1 FILLING THE UNIT	12
	2.2 Quick Change Power Pack (Battery) Charging	12
	2.3 UniVac Operation	
	2.4 Emptying Vacuum Tank	
3.0 N	Maintenance	
	3.1 Quick Change Power Pack (Battery) Electrical Diagram	15
	3.2 AC Corded Electrical Diagram	
4.0 Pc	arts Diagrams and Specifications	
	4.1 Vacuum Tank Assembly Parts Diagram	17
	4.2 VACUUM HEAD ASSEMBLY PARTS DIAGRAM	18
	4 3 OLIICK CHANGE POWER PACK (BATTERY) ASSEMBLY PARTS DIAGRAM	18

1.1 PRODUCT IDENTIFICATION





1.2 WARRANTY REGISTRATION

Thank you for purchasing a Kaivac product. Please take a few moments to register your product at kaivac.com/warranty.

Why register?

- Ensure your warranty coverage
- Simplify warranty service in the future with your information on file
- Be the first to know about upgrades, issues, new options and special offers.

1.3 LIMITED WARRANTY PROTECTION PLAN

<u>5 YEAR TROLLEY/TANK AND 1 YEAR PARTS AND LABOR (EXCLUDING BATTERY)</u> Kaivac warrants to the original purchaser/user that the vacuum tank and bucket body are free from defects in workmanship and materials under normal use for a period of Five Years, and the battery interface and components (excluding Lithium-ion battery), vacuum motor, and spray system are free from defects in workmanship and materials under normal use for a period of One Year. This warranty does not include accessories or wear items. Items EXCLUDED from coverage: Squeegee blades and wheels, hoses, seals, gaskets, cords, casters, HEPA filter cartridges, chemical feed caps, spray gun, GFCI, vacuum wand assembly and other accessory tools.

• Please Note: using inappropriate chemicals constitutes misuse of these machines. These machines are not meant to be used with high-foaming or corrosive chemicals. Please check with your distributor or with Kaivac if you have questions about your chemical.

Battery Program Details

- Battery Warranty covers 2 years on a defective Battery.
- Battery Warranty covers the replacement of the Battery unit.
- Battery replacement remains under Warranty only for the remaining Warranty period of the original Battery unit (for a maximum of 2 years from the date of purchase of the machine.

WARRANTY LIMITATIONS:

- This warranty does not assume responsibility for damage or faulty performance caused by misuse or abuse, or where repairs or modifications have been made or attempted. Kaivac will make the final determination on whether the damage falls under this limited warranty for manufacturer's defects.
- The following actions constitute misuse or neglect of the battery that void the warranty of the battery:
 - Any modifications to Kaivac equipment may nullify any warranty
 - Improper installation of the OmniFlex battery box
 - Exposure to temperatures above the battery limits
 - Use of any charger besides the supplied OmniFlex charger
 - Dropping the battery box
 - Long term storage of the battery without maintaining a battery charge of 25 to 40% capacity
- Under no circumstances will Kaivac be liable for any loss, damage, expenses or consequential damages arising
 in connection with the use or inability to use Kaivac's product. This warranty is in lieu of any other warranty
 expressed or implied, including any warranty of merchantability or fitness for a particular purpose.

1.4 SAFETY PRECAUTIONS: CORDED UNITS ONLY

IMPORTANT SAFETY INSTRUCTIONS — SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USING (THIS APPLIANCE)

When using an electrical appliance, basic precautions should always be followed, including the following:



WARNING: To reduce the risk of fire, electric shock, or injury:

- Turn off the unit before unplugging. Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- Connect to a properly grounded outlet only. Do not remove ground pin. See Grounding Instructions below.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Inspect cord prior to use. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors or dropped into water, return it to a service center.
- Do not handle plug or appliance with wet hands.
- Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts. Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- If using extension cord with appliance, make sure the connection is above the floor and away from exposure to liquid.
- Keep all connections dry and off the ground.
- To reduce the risk of injury, close supervision is necessary when a product is used near children.
- Stay alert watch what you are doing.
- Keep operating area clear of all persons.
- The Kaivac shall be disconnected from mains during cleaning or maintenance and when replacing parts or converting the machine to another function.
- Turn off all controls before unplugging.
- DO NOT overreach or stand on unstable support. Keep good footing and balance at all times.
- DO NOT operate without the float installed. If float is removed, reinstall by screwing back into place.
- Keep the cord away from heated surfaces.
- DO NOT leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- To Reduce The Risk Of Electric Shock Do not expose to rain. Store indoors.
- DO NOT use without dust bag and/or filters in place.
- Personal Protective Equipment (PPE): It is recommended to wear proper personal protective equipment as required by the chemical product label instructions used in conjunction with the appliance.
- This product comes with a grounded attachable extension cord. If damaged, replace with equivalent cord. This cord must be attached and mechanically secured using the provided cord connector to use the equipment.
- **WARNING** Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance if it will not fit the outlet; have a proper outlet installed by a qualified electrician.
- DO NOT operate the product when fatigued or under the influence of alcohol or drugs.
- Know how to stop the product and bleed pressures quickly. Be thoroughly familiar with the controls.
- Follow the maintenance instructions specified in the manual.

1.4 SAFETY PRECAUTIONS: CORDED (CONTINUED)

SPRAY SYSTEM WARNINGS (ONLY):

- Do not spray liquid from the Kaivac onto electrical outlets or any electrical devices.
- Risk of injection or injury to persons do not direct discharge stream at persons.
- INJECTION HAZARD: Equipment can cause serious injury if the spray permeates the skin. Do not point the gun at anyone or any part of the body. In case of permeation, seek medical aid immediately.
- This system is capable of producing 500 PSI (3447 kPa). To avoid rupture and injury, do not operate this pump with components rated less than 500 PSI (3447 kPa) working pressure (including but not limited to spray guns, hose, and hose connections); and before servicing, cleaning or removal of any part, shut off power and relieve pressure.
- High pressure cleaners shall not be used by children, persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge or untrained personnel. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This product may also have been provided with a ground fault circuit interrupter built into the power cord. If replacement of the plug or cord is needed, use only identical replacement parts.
- Test the ground fault circuit interrupter (GFCI) before each use.

GROUND FAULT CIRCUIT INTERRUPTER PROTECTION (for spray systems only)

This machine was supplied with a ground-fault circuit-interrupter(GFCI) built into the plug of the power-supply cord. This device provides additional protection from the risk of electric shock. Should replacement of the plug or cord become necessary, use only identical replacement parts that include GFCI protection.

This appliance is for use on a nominal circuit and has a grounding attachment plug. Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adapter should be used with this appliance.

GROUNDING INSTRUCTIONS

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local does and ordinances.

FOR INDOOR USE ONLY

INTENDED FOR COMMERCIAL USE



WARNING — To Reduce the Risk of Electric Shock — Do not expose to rain. Store indoors.

1.5 SAFETY PRECAUTIONS: BATTERY OPERATED UNITS ONLY

IMPORTANT SAFETY INSTRUCTIONS — SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USING (THIS APPLIANCE)

When using an electrical appliance, basic precautions should always be followed, including the following:



WARNING: To reduce the risk of fire, electric shock, or injury:

- ONLY USE with Kaivac, Inc. battery, OBATT series, and charger, CHARG36V series.
- When charging, make sure charger has at least 6 inches of clearance on all sides for adequate air flow.
- DO NOT charge batteries outdoors.
- DO NOT attempt to repair, service or modify the batteries or charger. Contact Kaivac Technical Support with any issues.
- DO NOT short-circuit the battery or charger terminals with conductive items such as paper clips. This can deliver high current, resulting in heat and fire.
- Keep sparks and flames away from batteries.
- DO NOT crush, drop, incinerate or damage the Battery Box. Do NOT use a Battery Box that has been damaged in any way. DO
 NOT incinerate the battery even if it is non-working or severely damaged. The battery can explode in a fire.
- DO NOT expose a Battery pack or appliance to fire or excessive temperature. Exposure to fire or temperature above 265°F (130°C) may cause explosion.
- DO NOT use or store the Battery in wet or moist conditions, or near flammable or combustible materials.
- DO NOT charge or store Battery Box for extended time (1 month or more) in temperatures below 40°F (4°C).
- If fumes smelled from battery, discontinue use immediately, place inside a metal canister in a well-ventilated area.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance. Carrying the appliance with your finger on the switch, or energizing an appliance that has the switch on invites accidents.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, or storing appliance. Such preventive safety measures reduce the risk of starting the appliance accidentally.
- When battery pack is not in use, keep it away from other metal objects like paper clips, coins, keys, nails, screws or other small metal objects that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with
 water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.

Charger/Electrical Warnings:

- For commercial or residential use.
- Connect charging cord to a properly grounded outlet only. See Grounding Instructions.
- DO NOT plug in Charger while Vacuum Head is in ON position. It may damage the system.
- Follow all charging instructions and do not charge the battery pack or appliance outside of the temperature range specified
 in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and
 increase the risk of fire.
- DO NOT leave charger plugged in when not in use.
- DO NOT operate charger if it has received a sharp blow, been dropped, or damaged in any way.
- DO NOT use charger if it has a damaged cord or plug. DO NOT carry charger by cord.
- DO NOT pull on charger cord to unplug. Grasp and pull the plug, not the cord.
- DO NOT handle charger, including charger plug and charger terminals, with wet hands while charger is plugged in or while
 inserting plug into electrical outlet.

Vacuum and operation warnings:

- NO COMBUSTIBLES! Sparks inside the motor can ignite flammable vapors or dust. Do not use near combustible liquids and
 gases, or to pick up explosive dusts or gasoline. Do not pick up anything that is burning or smoking such as cigarettes or hot
 ashes.
- DO NOT plug Battery in while Vacuum Motor is in ON position. It may damage the system.

1.5 SAFETY PRECAUTIONS: BATTERY OPERATED (CONTINUED)

- CHECK FLOAT on Vacuum Motor and clean before each use. Clogged screen may lead to loss of suction.
- DO NOT allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- DO NOT put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair and anything that
 may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Use extra care when cleaning on stairs.
- DO NOT use without Vacuum Motor Float Cage in place.

SPRAY SYSTEM WARNINGS (ONLY):

- Do not spray liquid from the Kaivac onto electrical outlets or any electrical devices.
- Risk of injection or injury to persons do not direct discharge stream at persons.
- INJECTION HAZARD: Equipment can cause serious injury if the spray permeates the skin. Do not point the gun at anyone or any part of the body. In case of permeation, seek medical aid immediately.
- This system is capable of producing 500 PSI (3447 kPa). To avoid rupture and injury, do not operate this pump with components rated less than 500 PSI (3447 kPa) working pressure (including but not limited to spray guns, hose, and hose connections); and before servicing, cleaning or removal of any part, shut off power and relieve pressure.
- High pressure cleaners shall not be used by children, persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge or untrained personnel. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This product comes with a grounded attachable extension cord. If damaged, replace with equivalent cord rated 120V, 15 amps, 3-wire, 14 GA. This cord must be attached and mechanically secured using the provided cord connector to use the equipment.

QUICK RELEASE INSTRUCTIONS

- 1. To disconnect the motor from the Battery Pack, pull the button on the electrical connector toward you and turn the electrical connector counter-clockwise 90 degrees to disengage the motor electrical cord from the Battery Pack.
- 2. Then to remove the Battery Pack from the OmniFlex unit, detach the straps which wrap around the metal handle. Then while standing at the rear of the OmniFlex, grab the Battery Pack on either side and pull it away from the OmniFlex unit.
- 3. To reconnect the Battery Pack to the electrical motor, insert the motor electrical connector into the Battery Pack outlet aligning the key features of the electrical connector into the outlet key-way. Press the connector into the outlet and turn clockwise 90 degrees until the connector locks into place.

GROUNDING INSTRUCTIONS

If appliance should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. If this appliance is equipped with a cord having equipment grounding conductor and grounding plug, the plug must be inserted into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING — Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance – if it will not fit the outlet; have a proper outlet installed by a qualified electrician.

This appliance is for use on a nominal circuit and has a grounding attachment plug. Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adapter should be used with this appliance.

Personal Protective Equipment (PPE): It is recommended to wear proper personal protective equipment as required by the Chemical product label instructions used in conjunction with the appliance.



WARNING — To Reduce the Risk of Electric Shock — Do not expose to rain. Store indoors.

1.6 BATTERY INFORMATION

Keep Batteries at Room Temperature: That means storing between 32 and 80 degrees F (0°C to 27°C). The worst thing that can happen to a lithium-ion Battery is to have it exposed to elevated temperatures.

Batteries Lose Capacity Over Time: Batteries naturally deteriorate over time whether being used or not. Batteries deteriorate at a rate of 10% run time per year.

Fully Discharge vs. Partial Discharge and the Effect on Battery Cycles: Unlike lead acid batteries typically used in auto scrubber, the Kaivac Battery is not damaged by fully discharging. The BMS (Battery Management System) has a cutoff voltage of 30V which protects the Battery from experiencing full discharge. Running the Battery to full discharge will reduce the amount of charge cycles. The expected hours of use are approximately 600 hours. For example, if running to full discharge, you would expect 400 cycles. If you run to 80% discharge, then you would expect to get more cycles (500 cycles).

Extended Storage: It is recommended to discharge to 40% capacity (35V) and store in a cool location (between 32°F to 80°F or 0°C to 27°C). Hour

Battery Gauge: The Kaivac Batteries come with a built-in Battery Gauge or "Fuel Gauge" which shows the approximate run time remaining.


Disposal: Properly dispose of Battery at a local recycling location.

Battery Specifications	
Weight	With Box, 11 lbs. (4,9 kg)
Body Material	Injection Mold Polypropylene
Dimensions (H x W x D)	18 x 7 x 5 in. (45,7 x 17,8 x 12,7 cm)
Voltage	36V DC
Battery Capacity	15 A-hr
Battery Current	15 A DC
Battery Type	Lithium-lon
Approx. Run Time BOL (Beginning of Life)	60 minutes
Approx. Run Time EOL (End of Life)	35 minutes (discontinue use and take to recycling center)
Battery Box Receptacle	IP65 / IP67 (not required for UL)
Run Time Hour Meter	Acts as "odometer for battery" and runs only when motor switch is ON
Approx. Charge Cycles	400 @ 100% discharge / 500 @ 80% discharge
Cut off Voltage (fully discharged)	30V
Charger Specifications	
Approx. Charge Time	5.5 hours
Charger Amps	4 Amps
Charge Voltage	42V DC
Charger Voltage	110-240VAC / 36VDC (240VAC version only needs correct plug for wall outlet)
Charging Robustness	No special instructions
Battery Charge Memory	None
Battery Charge Gauge	Yes, LED Indicator
Approx. Charge Cycles	400 @ 100% discharge / 500 @ 80% discharge
Storage/Inventory:	
Storage & Operation Ambient Temp	32°F (0°C) to 80°F(27°C)
Storage & Shipping Charge	40-60% Charge (35-38VDC)

2.1 FILLING THE UNIT

<u>CAUTION:</u> Before filling with solution, ensure the spigot is in the "OFF" position.






Fill the tank with water and recommended amount of **Kaivac approved Chemicals**. Follow the proper dilution instructions on bottles or dispenser. For accuracy and convenience, use Kaivac proportioned chemical packets.

TIP: IF A CHEMICAL IS BEING USED, USE ONLY THE RECOMMENDED DILUTION.

2.2 QUICK CHANGE POWER PACK (BATTERY) CHARGING

Push tab on plug and pull, to unplug head from battery.













Ensure the Charging Mount is plugged in.

You may optionally charge battery while still mounted on machine





Battery needs to be in unlock position to remove.



machine mount.

Once in place, turn key clockwise to OFF to lock in place.






Push key IN and rotate counter clockwise to Unlock.

2.3 UNIVAC OPERATION


Cleaning with OmniFlex Dispense-and-Vac mode is better, safer and faster than cleaning with a mop. You apply fresh cleaning solution to the floor, spread and lightly brush into grout lines, then vacuum away all soils and liquids.

After the unit has been filled with the appropriate amount of water/chemical, turn the Spigot handle counter clockwise to MAX position.


Beginning at the rear of the area, begin dispensing solution, moving towards the front of the area. Park unit so that it blocks entry to area.



Turn Vacuum Motor to ON. Attach Vacuum Wand to Vacuum Hose (if not already connected).




Vacuum floor surface diagonally to grout lines, reaching under shelves, seating etc.



Turn Spigot clockwise to the OFF position. Use Spreader Tool in back-and-forth motion to cover floor with cleaning solution. *Agitate Spreader Tool over troubled or extra soiled areas to get a deeper clean*

Slap & Tap: Once Vacuuming is complete, keep motor running. Slap Vacuum Wand on floor 3-4 times to dislodge debris from squeegee head. Then, invert Wand and Tap 4-5 times to dislodge any fluids or substance from Wand.




Then Turn OFF Motor.

2.4 EMPTYING VACUUM TANK


If the Vacuum Motor shuts off before the job is complete, the Vacuum Tank may be full and need to be emptied. Lift the Vacuum Motor to check liquid level inside the Vacuum Tank. If unit is full or your job is complete, follow the instructions below to empty Tank into appropriate sink/drain.

To begin the dumping process, you must first press down on the Cap and turn counter-clockwise





Once cap is removed, lower Dump Hose into appropriate sink/drain. To prevent an accidental spill or overflow from the Dump Hose, be careful to keep hose end upright until it is over sink/drain.

Before starting each new cleaning process, remove Filter Bag, dump any debris out, spray clean, and then replace back into the Filter Bag Frame.




3.1 DC QUICK CHANGE POWER PACK (BATTERY) ELECTRICAL DIAGRAM






3.2 AC CORDED ELECTRICAL DIAGRAM




4.1 VACUUM TANK ASSEMBLY PARTS DIAGRAM [P/N: OVTAU2, OVTAU3]



#	PART NO.	PART DESCRIPTION		
1	OSTOB2	OMNIFLEX MULTI PURPOSE POST - HOSE PORT		
2	CLASP1Y	OMNIFLEX CLASP UPPER YELLOW		
3	CSS209	8-32 X 3/4 ROUND HEAD MACHINE SCREW (AC ONLY)		
4	CSS306	WASHER BONDED NEOPRENE 1/4ID X 5/8OD (AC ONLY)		
5	оѕтов	OMNIFLEX MULTI PURPOSE POST		
6	CSS322	10 X 3/4 PHL PAN HI-LO (AC ONLY)		
7	CSS211	8/32 IN. INSERT FOR MOLDS (AC ONLY)		
8	VHDTY	VAC HOSE DRIP TRAY		
9	CSS208	8 X 1/2 SS TRUSS SCREW		
10	CSS365	1/2-13 SST LOCKING NUT (DC ONLY)		
11	CSS40	1/2 DIA WASHER (DC ONLY)		


12	OTKG	UNIVAC OUTRIGGER TOE KICK GUARD (DC ONLY)	
13	OBRAK	OUTRIGGER BRACKET (DC ONLY)	
14	OFCSTR2	OMNI 3IN CASTER NO BRAKE THREADED STEM (DC)	
15	OEXTLEGB	OMNIFLEX EXTENSION LEG B	
16	OEXTLEGA	OMNIFLEX EXTENSION LEG A (ONLY 1 ON DC)	
17	OFCSTR	OMNIFLEX 3IN CASTER NO BRAKE	
18	PCSH	OMNIFLEX 1" SPIGOT ASSEMBLY	
19	OVTSHB	OMNIFLEX VAC TANK SPIGOT HANDLE BRACKET	
20	CSS329	1/4-10 X 1 PLASTITE ZINC PAN TORX 30	
21	KMB22A	OMNIFLEX SPIGOT BLACK PLASTIC	
22	QCINTA	QUICK CHANGE INTERFACE	
23	OBAGY	MESH BAG (YELLOW)	

4.2 VACUUM HEAD ASSEMBLY PARTS DIAGRAM [P/N: VMAWDZ2, VMAWDZDC2, VM-UL-AWDZDC2, VM-UL-AWDZT2]




#	PART NO.	PART DESCRIPTION		
1	CSS17A	8 SST SCREW 3/4 IN		
2	OVMHANLP	OMNIFLEX VAC MOTOR HANDLE BLACK LOW PROFILE		
3	ZD10TC	OMNI VAC MOTOR TOP COVER		
4	ZD10MC	OMNI VAC MOTOR MIDDLE COVER		
5	ZD10MR	OMNI VAC MOTOR MIDDLE RING		
5	ZD10MR36	OMNI VAC MOTOR MIDDLE RING — 36V		
6	ZD10BC	OMNI VAC MOTOR BOTTOM COVER		
7	FCINT	FLOAT CAGE PLASTIC INTERFACE		
8	CSS318	5/6" SS PHILLIPS FOR ZD 10/FCINT		
9	CVS26	OMNIFLEX FLOAT BALL		
10	ZD10	STAINLESS STEEL FLOAT CAGE		
11	CSS313	SCREW #7 PANHEAD PHIL SS 1/2 IN		
12	ZD10B	OMNI VAC MOTOR BASKET		
13	CSS315DC2	ELEC. MALE PLUG 36VDC 20A		
13	CSS315AU	AUS PLUG IP44		
13	CSS315UK	UK PLUG IP44		

4.3 QUICK CHANGE POWER PACK (BATTERY) PARTS DIAGRAM



#	PART NO.	PART DESCRIPTION		
1	OBATT2	QUICK CHANGE POWER PACK		
2	QCINTA	QUICK CHANGE INTERFACE		
3	CSS314DC2	METAL STRAIGHT ELEC FEMALE RECEPTABLE 36VDC 20A		
4	CSS366	10-14 X 3/4 IN PLASTITE FLAT TORX		
5	CHARG36VUL4	BATTERY CHARGER 120VAC-36VDC		
5	CHARG36VI	BATTERY CHARGER 120VAC-36VDC		



Page | 19 www.kaivac.com